

How to Cancel Speed Limit

To ensure safety of customers, all our ATVs come with speed limit, the maximum speed is only 9KM/H when you just received it. To make it go faster, please follow these instructions:

Step 1. Remove the ATV seat cushion:


Locate the "seat latch" under the bottom of the seat cushion as below picture shows, then pull it backward until the cushion comes loose.



1. Seat latch. 2. Stopping Block

Step 2. Find the "red three-hole plug":

After the seat cushion was removed then you will see the wire harness right under where you supposed to sit. Locate the unconnected "red three-hole plug" as below picture Point ① shows.



① Red three-hole plug

② Red three-hole connector



Red three-hole plug

Step 3. Find the “red three-hole connector”:

Within the connected wire harness locate the “red three-hole connector” and unplug it. See the above picture Point ②.

Step 4. Connect ① and ②

Step 5. Organize the wire harness:

Organize and secure the wire harness.

Step 6. Install the seat:

Insert the “stopping block” of the cushion into the corresponding limiting slot of the frame then press the cushion till it fits well with the vehicle, and finally push the “seat latch” forward till the cushion is secured.

Now the speed limit is canceled, you can adjust the speed function switch to "H" on your left handle bar twisting the right handle bar accelerator and enjoy the max speed.